




Installation guide

ALU THERMOWOOD

Alu ThermoWood Panels

FibroTech Alu ThermoWood panels are exterior cladding elements developed for outdoor applications such as façades, fences, and feature walls. The panels combine thermally modified solid wood with an aluminium backing contributing to strength and stability. This construction provides a natural appearance designed to provide durability, stability and resistance to normal weather exposure.

The aluminium base adds structural strength and dimensional stability, while the ThermoWood surface delivers a warm and exclusive finish suitable for modern architecture.



Content

Product Overview	Page 4
Recommended Tools & Materials	Page 6
Recommended Safety Information	Page 6
Installation Procedure	Page 7

Application details and special solutions

Outside Corner Profile	Page 12
Inside Corner Profile.....	Page 13
Bottom/Divider Profile – Bottom.....	Page 14
Bottom/Divider Profile – Divider	Page 15
Insect Mesh Profile	Page 16
Cover- and Top/Side Profiles.....	Page 17
Start/End Profile with rear battens.....	Page 18
Top/Side Profile (installation without rear battens).....	Page 19
Door/Window Sill Profile	Page 20
Coverage Profile – Window	Page 21
Coverage Profile – Door	Page 22

Product Overview

Panel specifications

Panel dimensions: 25 × 194.5 × 2400 mm

Aluminium thickness: 1 mm

Integrated overlap design for effective water shedding


Panels are available in the following finishes:




FibroTech Alu ThermoWood
Natural



FibroTech Alu ThermoWood
Oiled



FibroTech Alu ThermoWood
Grey



FibroTech Alu ThermoWood
Black

Accessories

A complete range of 1 mm thick aluminium profiles powder coated in a matte black finish to match the FibroTech Alu and Alu ThermoWood panel series.

All accessory profiles are supplied in standard lengths of 2400 mm and can be cut to length using appropriate tools for aluminium/metal.

Mounting

Installation requires approved mounting screws, rear battens/furring strips, and a suitable weather-resistant barrier (WRB) where required by local building standards.



FibroTech
Alu Panel Screw
4.8 x 35 mm TX20



FibroTech
Start/End Profile




FibroTech
Outside Corner Profile



FibroTech
Inside Corner Profile



FibroTech
Bottom/Divider Profile




FibroTech
Insect Mesh Profile



FibroTech
Cover Profile 200 mm



FibroTech
Cover Profile 250 mm



FibroTech
Door/Window Sill Profile



FibroTech
Coverage Profile



FibroTech
Top/Side Profile


Recommended Tools & Materials




Measuring rule




Pencil or marker




Spirit level




Power drill



T20 Torx Bit Driver



Circular saw



Utility knife



Metal snips

Recommended Safety Information



**Always wear
protective gloves
and safety glasses**



**Use correct lifting
techniques when
handling panels**



**Follow all local
building regulations**







**Avoid installation
during extreme
weather conditions
such as heavy rain
or strong winds**

Installation Procedure


Install battens / furring strips horizontally

Install battens horizontally as standard. Always use a weather-resistant barrier behind the battens when required.




Install battens / furring strips vertically (optional)

Optional vertical battens may be used where required by design or profile configuration. Always use a weather-resistant barrier behind the battens when required.



Battens should be evenly spaced approx. 600 mm between.


Make cuts if necessary for proper panel and or trim fitment



All cuts must be made using an all-purpose blade suitable for aluminium.

Step 1: Start/End Profiles



Install FibroTech Start/End Profiles along the bottom and side edges before mounting panels. Start/End Profiles protect against moisture ingress and provide correct panel alignment.



Example!

Step 2: Mounting the first panel



Begin installation from the side, typically from right to left (both directions are possible).



- Begin installation from the side, typically from right to left (both directions are possible).
- Position the panel and verify vertical alignment using a level.
- Ensure screws align with the rear battens (8 screws pr. panel).
- Tighten screws carefully; compress the washer without overtightening.

Step 3: Installing additional panels

- Mount the panels together.
- Check alignment frequently to maintain a straight and vertical façade.
- Continue the process across the installation area.




Step 4: Finishing and quality check

- Inspect all fixings and overlaps.
- Confirm correct drainage gaps and profile placement.
- Ensure all trims and profiles are correctly seated and secured.





Application details and special solutions

Outside Corner Profile



Application details and special solutions


Inside Corner Profile



This piece can also be used to join a wall and ceiling.

Application details and special solutions

Bottom/Divider Profile - Bottom




TIP

Leave a drainage gap below bottom trims to prevent water accumulation.

Panels may be installed up to 70 mm above the drainage edge if required.

Application details and special solutions

Bottom/Divider Profile - Divider



TIP


Ensure the divider trim is level and continuous, and allow a small expansion gap at joints. Do not block the drainage path when fixing the profile.

Application details and special solutions

Insect Mesh Profile

TIP

Insect mesh is recommended for residential buildings but optional for sheds, fences, and simple wall constructions.




Application details and special solutions

Cover Profile and Top/Side Profiles


TIP

Use FibroTech
installation adhesive.




Application details and special solutions

Start/End profile with rear battens




Application details and special solutions

Top/Side Profile (installation without rear battens)



Application details and special solutions

Door/Window Sill Profile






TIP

For window and door installations, cut and bend coverage profiles to match the opening precisely. Allow sufficient clearance for drainage and movement where necessary.

Application details and special solutions

Coverage Profile - Window






Application details and special solutions

Coverage Profile - Door

TIP

For window and door installations, cut and bend coverage profiles to match the opening precisely. Allow sufficient clearance for drainage and movement where necessary.





Certificeringer, brandklassifikationer og miljødokumentation afhænger af produktvariant og anvendelse. Relevante certifikater og overensstemmelseserklæringer kan rekvireres. Der kan ikke udledes nogen rettigheder af dette dokument. Der tages forbehold for ændringer, taste- og trykfejl.
Scan for opdateret version: <https://fibrotech.com/en/installation-instructions/>

TreeTops Trading A/S . Bavnevej 32 . DK-6580 Vamdrup . Tlf.: +45 70 266 233 . info@treetops.dk . www.treetops.dk

Vers: TT 001
02.07.2026